



Maintenance and Cleaning Instructions **For Menu Cases**

Lacquered Bright Metal Parts

In order to prolong the life of the protective lacquer, regular cleaning with water containing liquid detergent (i.e. Washing up liquid) is beneficial. A soft cloth soaked in the water detergent mix should be used whilst rinsing the cloth regularly to remove any particles that may scratch / damage the lacquer. Buff with a soft dry cloth to remove water marks. Under no circumstances should abrasive cleaners be used.

Non-Lacquered Bright Metal Parts

To be polished regularly with a soft cloth and a proprietary metal cleaner (i.e. Brasso) used where necessary to restore the polished finish. Abrasive cleaners should not be used.

Painted Metal Parts

Care should be used to avoid damaging the paint; therefore it is recommended that the procedure for lacquered metal parts is followed.

Plastics

Care should be taken as they are less resistant to scratching. Warm water with a small amount of liquid detergent and a soft cloth is recommended.

Hardware

Locks and hinges require minimal maintenance. A small amount of machine oil applied occasionally will ensure ease of operation.

Felt Pinboards

To prevent premature aging avoid positioning in direct sunlight. Felt may be cleaned with a soft brush or light strokes with a lint free cloth.